

Quick Start Guide for Interactive Kiosk

This is a large format interactive kiosk ready for Windows or Android based media player with HDMI port and power socket ready for extra media player.

1. Open the Box

In the box, there are kiosk, key, remote control HDMI cable and USB cable provided.

2. Power on the kiosk:

Open the rear door of the kiosk with the key provided. Power it on with the power cord. The kiosk is set as default power on after plug in the main power cord. There is also switch button inside the rear door.

3. Connections:

Put the mini media player inside the rear door and plug the power into the power socket to power on the media player. Connect the HDMI port for video signal and USB cable for touch screen.

4. Set the box on

After all the connections are done, please turn all the switches on for both the kiosk and the media player on. Make sure the setting on the media player is alright. Then start to use the kiosk.

5. Screen settings:

There is a remote control included in the box to do the displays settings. Press Menu button to get into the OSD. There is a password required to get into the OSD which is 000000. You could select the input source and set the screen configuration like the brightness, contrast and others by the remote control.